

Part Numbers (Korry numbers in alphanumeric order; OEM numbers are referenced)	Aircraft Type (when applicable)	Document (doc. # / type / title / rev. date)
Korry 09-530-0XXX Boeing S231W240-XXX	777-ALL	ATA 31-12-01 Component Maintenance Manual Lighted Pushbutton Switch Rev. 11, 12/18/2012
Korry 09-530-0XXX Boeing S231W240-XX	777-ALL	ATA 09-530-31-01 Service Bulletin Lighted Pushbutton Switch - Replacement Rev. 1, 7/16/1998
Korry 088-515-1031-0XX	727, 727-100, 727C, 727-100C, 727-200, 727-200F 737-100, 737-200, 737-200C, 737-300, 737-400, 737-500, 737- 600, 737-700, 737-700C, 737- 800, 737-900	ATA 088-33-01 Service Bulletin Indicator Light Assembly Rev. 2, 4/15/2005
Korry 088-515-1031-106, -107	737-600, 737-700, 737-700C, 737-800, 737-900	ATA 088-33-02 Service Bulletin Indicator Light Assembly Original, 2/3/2006
Korry 303-1001-001	747-ALL, except -400 SOME A/C ONLY	SB 1 Service Bulletin Switch Assembly – Lubrication Required on Some Switches Original, 12/1/1970
Korry 311-711-1022-001 311-711-1022-003 311-711-1023-001 311-711-1023-004 311-711-1024-001 311-711-1024-002 311-711-1026-001 311-711-1026-006 311-711-1026-011 311-711-1026-016 311-711-1026-017 Boeing 311-711-1022-001 311-711-1022-003 311-711-1023-001 311-711-1023-004 311-711-1024-001 311-711-1024-002 311-711-1026-001 311-711-1026-006 311-711-1026-011	757-ALL 767-ALL	ATA 33-10-04 Component Maintenance Manual Lighted Pushbutton Switch Indicator Matrix Rev. --, 5/1/1995

311-711-1026-016 311-711-1026-017		
Korry 311-711-1029-001 311-711-1029-004 311-711-1029-007 311-711-1029-010 Boeing 60B40152-1 6040152-2 60B40152-3 60B40152-4	747-ALL, except 747-400, -800	ATA 33-10-02 (replaced obsolete 31-10-02) Component Maintenance Manual Autothrottle Mode Select Switch Assembly Rev. 4, 8/28/1998
Korry 311-711-1029-001, -004 Boeing 60B40152-1, -2	747-ALL, except -400	SB 18 Service Bulletin Switch Assembly – Blue Color Upgrade Original, 8/25/1983
Korry 317-631-1001-XXX 317-631-1002-XXX 318-630-1001-XXX 318-630-1002-XXX Boeing 10-61803-XXX	727-ALL 737-ALL	ATA 33-10-05 Component Maintenance Manual Indicator Light Assembly (Press to Test) (Incandescent and LED) Rev. --, 4/1/2003
Korry 317-631-1001-XXX 317-631-1002-XXX 318-630-1001-XXX 318-630-1002-XXX 317-631-2001-XXX 317-631-2002-XXX 318-630-2001-XXX 318-630-2002-XXX 318-630-2010-XXX 318-630-2011-XXX Boeing 10-61803-XXX	727-ALL 737-ALL	ATA 33-10-06 Component Maintenance Manual Indicator Light Assembly (Press to Test) (Incandescent and LED) Rev. --, 4/1/1999
Korry 317-631-100X-XXX 318-630-100X-XXX Boeing 10-61803-XX	707-ALL 727-ALL 737-ALL	SB 15 Service Bulletin Lighted Annunciators – Press to Test Failures Original, 10/15/1973
Korry 318-630-1001-XXX 318-630-1002-XXX Boeing 10-61803-XXX	737-ALL	ATA 318-33-01 Service Bulletin Indicator Light Assembly – Cap Replacement Original, 4/5/1996

<p>Korry 318-630-1001-XXX 318-630-1002-XXX</p> <p>Boeing 10-61803-XXX</p>	737-ALL	<p>ATA 318-33-02 Service Bulletin Indicator Light Assembly – Cap Replacement Original, 7/15/1996</p>
<p>Korry 318-630-1001-XXX 318-630-1002-XXX</p> <p>Boeing 10-61803-XXX</p>	737-ALL	<p>ATA 318-33-03 Service Bulletin Indicator Light Assembly – Inspection/Replacement of Terminal Plate Sub-Assembly Rev. 1, 7/12/1999</p>
<p>Korry 318-630-1001-XXX 318-630-1002-XXX</p> <p>Boeing 10-61803-XXX</p>	737-ALL	<p>ATA 318-33-04 Service Information Letter Terminal Plate Upgrade Original, 3/8/2001</p>
<p>Korry 318-630-1001-XXX 318-630-1002-XXX</p> <p>Boeing 10-61803-XXX</p>	737-ALL	<p>ATA 318-33-05 Service Information Letter Blue Cap Assembly Brightness Original, 8/22/2001</p>
<p>Korry 318-630-1001-XXX 318-630-1002-XXX</p> <p>Boeing 10-61803-XXX</p>	737-ALL	<p>ATA 318-33-06 Service Information Letter Korry Light Assembly, Press-to-Test Indicator – Terminal Plate Upgrade Original, 1/27/2003</p>
<p>Korry 332-632-XXXX (332-632-0980 through 332-632-1186)</p> <p>Boeing 60B00148-XX</p>	747-ALL, except -400, -800	<p>ATA 33-10-14 (replaced obsolete 31-10-14, 33-11-11, 33-11-12, and 33-11-13) Component Maintenance Manual Switch Display Indicators 332 Series Rev. 6, 10/12/1998</p>
<p>Korry 332-632-XXXX-01</p> <p>Boeing 60B00148-XX</p>	747-ALL, except -400, -800	<p>SB2 Service Bulletin Lighted Pushbutton Switch Assembly - Premature Failure of Electrical Switch Module Original, 6/20/1972</p>
<p>Korry 332-632-XXXX-XXX</p> <p>Boeing 60B00148-XX</p>	747-ALL, except -400, -800	<p>SB17 Service Bulletin Lighted Pushbutton Switch Assembly – Mounting Brackets Rev. C, 2/20/1984</p>

<p>Korry 332-632-XXXX-XXX</p> <p>Boeing 60B00148-4, -24, -42, -50</p>	<p>747-ALL, except -400, -800</p>	<p>SB19 Service Bulletin Lighted Pushbutton Switch Assembly – Cap Shaft and Mounting Tab Change Rev. E, 6/26/1987</p>
<p>Korry 332-632-1XXX-XX</p> <p>Boeing 60B00148-83, -85, -90</p>	<p>747-ALL, except -400, -800</p>	<p>ATA 332-31-01 Service Bulletin Lighted Pushbutton Switch Assembly - Mounting Panel Thickness Original, 7/11/1991</p>
<p>Korry 332-632-1026-01</p> <p>Boeing 60B00148-12</p>	<p>747-ALL, except -400, -800</p>	<p>SB5 Service Bulletin Lighted Pushbutton Switch Assembly- Possible improper assembly on Serial numbers prior to 911 Original, 6/20/1972</p>
<p>Korry 341-640-1008-01 341-640-1008-02 341-640-1008-03 341-640-1008-04</p> <p>Boeing 60B00121-6 through -9</p>	<p>747-ALL, except -400, -800</p>	<p>SB4 Service Bulletin Flight Mode Annunciator Original, 4/1972</p>
<p>Korry 341-640-1008-03 341-640-1008-04 341-640-1008-05 341-640-1008-06 341-640-1008-07</p> <p>Boeing 60B00121-8 60B00121-9 60B00121-10 60B00121-11 60B00121-12</p>	<p>747-ALL, except -400, -800</p>	<p>ATA 33-11-21 Component Maintenance Manual 341 Flight Mode Annunciator Rev. 4, 8/31/2004</p>
<p>Korry 411-811-0982-001R (discontinued) 411-811-0982-002 (disc.) 411-811-0982-003 (disc.) 411-811-0982-004 (disc.) For new applications use 14120-XXX</p> <p>Boeing 411-811-0982-001R 411-811-0982-002</p>	<p>757-ALL 767-ALL manufactured prior to 1991; after 1991 use 14120-XXX</p>	<p>ATA 33-10-17 (replaced obsolete 31-10-17) Component Maintenance Manual Lighted Pushbutton Switch Indicator Assembly Rev. 8, 7/1998</p>

411-811-0982-003 411-811-0982-004		
Korry 433-673-1001-1XXX Boeing S231T290-1XXX	757-200 767-ALL manufactured prior to 1986	SB 23 Service Bulletin Lighted Pushbutton Switch Assembly - Mounting Instructions and Out of Sync Condition Original, 7/9/1986
Korry 433-673-1001-1XXX Boeing S231T290-1XXX	757-200, 767-ALL, and 737-300 manufactured prior to 1986	PS-224 Service Information Letter Lighted Pushbutton Switch Assembly - 1000 Series Green Dot Upgrade Original, 1/1/1987
Korry 433-673-1001-1XXX 433-673-1004-1XXX Boeing ST231T290-1XXXX S231T290-4XXXX	737-300, -400, -500 747-400 757-200 767-ALL	PS-226 Service Information Letter Lighted Pushbutton Switch Assembly - Early 4000 Series Anomalies Original, 1/5/1990
Korry 433-673-1001-1XXX 433-673-1004-1XXX Boeing ST231T290-1XXXX S231T290-4XXXX	737-300, -400, -500 747-400 757-200 767-ALL	ATA 433-33-01 Service Bulletin Lighted Pushbutton Switch Assembly - Configuration "C" Modification Original, 3/22/1990
Korry 433-673-1001-1XXX 433-673-1004-4XXX Boeing ST231T290-1XXXX S231T290-4XXXX	737-300, -400, -500 747-400 757-200 767-ALL	ATA 433-33-04 Service Bulletin Lighted Pushbutton Switch Assembly - Master Module Replacement and Configuration "D" Upgrade REV. 1, 3/12/1999
Korry 433-673-1001-1001 through -1105 433-673-1004-4001 through -4125 Boeing S231T290-1001 through -1105 S231T290-4001 through -4125	737-ALL 747-400 757-ALL 767-ALL	ATA 433-33-05 Service Bulletin Indicating and Reporting Systems – Lighted Pushbutton Switch - Replacement Original, 7/23/2001
Korry 433-673-1004-1XXX Boeing S231T290-4XXX	737-300 747-400 757-200 767-ALL	PS-225 Service Information Letter Lighted Pushbutton Switch Assembly - 4000 Series Switch Introduction Original, 8/10/1988

<p>Korry 433-673-1004-4XXX</p> <p>Boeing S231T290-4XXXX</p>	<p>737-300, -400, -500 747-400 757-200 767-ALL</p>	<p>PS-230 Service Information Letter Lighted Pushbutton Switch Assembly - Cap Pop-Up Anomaly Original, 10/9/1989</p>
<p>Korry 433-673-1004-4XXX</p> <p>Boeing S231T290-4XXXX</p>	<p>737 747-400 757-200 767-ALL</p>	<p>ATA 433-33-02 Service Bulletin Lighted Pushbutton Switch Assembly - Lampholder Assembly Original, 5/30/1992</p>
<p>Korry 433-673-1001-1XXX 433-673-1004-4XXX</p> <p>Boeing S231T290-1XXX S231T290-4XXX</p>	<p>737-300, -400, -500 747-400, -800 757-ALL 767-ALL</p>	<p>ATA 33-10-20 (replaced obsolete 31-10-20) Component Maintenance Manual Lighted Pushbutton Switch Indicator Assembly Rev. 13, 12/2/2002</p>
<p>Korry 433-673-1001-1XXX 433-673-1004-4XXX 433-673-1006-6XXX</p> <p>Boeing ST231T290-1XXX ST231T290-4XXX</p>	<p>737-300, -400, -500 737NG 747-400, -800 757-ALL 767-ALL</p>	<p>ATA 33-10-21 Component Maintenance Manual Lighted Pushbutton Switch Indicator Assembly - LED 6XXX Series Rev. 2, 6/30/2005</p>
<p>Korry 433-673-1004-4001 through -4125</p> <p>Boeing S231T290-4001 through -4125</p>	<p>737-ALL 747-400 757-ALL 767-ALL</p>	<p>ATA 433-33-06 Service Bulletin Indicating and Recording Systems – Lighted Pushbutton Switch - Replacement Original, 11/7/2001</p>
<p>Korry 4336731004-42XX/43XX Series</p> <p>Boeing S231T290-42XX/43XX Series</p>	<p>737-300, -400, -500 737NG 747-400, -800 757-ALL 767-ALL</p>	<p>ATA 33-10-22 Component Maintenance Manual Lighted Pushbutton Switch Indicator Assembly Rev. 3, 9/1/2008</p>
<p>Korry 434-674-1005-(1XXX) 434-674-1031-(2XXX) 434-674-1007-1019 434-674-1032-2019 434-674-1009-(1XXX) 434-674-1033-(2XXX)</p> <p>Boeing S231T300-(1XXX) S231T300-(2XXX) S231T301-1104 S231T301-2104</p>	<p>747-400, -800 757-ALL 767-ALL</p>	<p>ATA 33-10-01 (replaced obsolete 31-09-01) Component Maintenance Manual Annunciator Light Assembly (Pull to Relamp) Rev. 11, 8/31/2002</p>

S231T301-(1XXX) S231T301-(2XXX)		
Korry 434-674-1005-(1XXX) 434-674-1042-(3XXX) 434-674-1043-(3XXX) 434-674-1031-(2XXX) 434-674-1007-1019 434-674-1032-2019 434-674-1009-(1XXX) 434-674-1033-(2XXX) 434-674-1041-(3XXX) Boeing S231T300-(1XXX) S231T300-(2XXX) S231T301-1104 S231T301-2104	747-400, -800 757-ALL 767-ALL	ATA 33-10-07 Component Maintenance Manual Incandescent and LED Annunciator Light Assembly (Pull to Relamp) Rev. --, 3/15/1999
Korry 434-674-1033-2203 through -2212 Boeing S231T301-2203 through -2212	757-200, -300 767-200, -300, -400	ATA 434-33-01 Service Information Letter Discrete Warning Display Cap Retention Reliability for Certain Date Codes Original, 10/10/2000
Korry 16445-XXX	MD-11, MD-11F 747-400 757-200 767-200, 767-300	ATA 427-33-01 Service Information Letter Light Switch Assembly – Cap Upgrade Original, 8/28/2000
Korry 20800-XXX Boeing 60B00149-XXX	747-100 through -300	ATA 20800-33-01 Service Information Letter Terminal Plate Upgrade Original, 4/6/2001
Korry 32500-XXX Boeing S231W240-XXX	777-ALL	ATA 777-33-01 Service Information Letter Lighted Pushbutton Switch Assembly Original, 6/1/2012
Korry 32500-XXX Boeing S231W240-XXX	777-ALL	ATA 31-12-02 Component Maintenance Manual LED Switch Assembly Rev. 1, 12/18/2012
Korry 33987-XXX Boeing S633Z001-XXX	787-ALL	ATA 787-33-01 Service Information Letter Alternate Action Lighted Pushbutton Switch Original, 8/16/2012

Korry 33987-3XX: -301 through -306, -308, -309, -312 through -319, - 323, -331, -336 through -342	787-ALL	ATA 31-10-21 Component Maintenance Manual Lighted Pushbutton Switch Rev. 3, 1/30/2013
Korry 33988-1XX: 33988-102, -104, -106, -107, -116 through -123	787-ALL	ATA 31-10-22 Component Maintenance Manual Annunciator Light Indicator Rev. 3, 3/1/2013
Korry 410100-002 Boeing S633Z001-101	787-ALL	ATA 24-22-01 Component Maintenance Manual Control Panel - Electrical Rev. 4, 9/14/2012
Korry 410200-001 Boeing S633Z001-120	787-ALL	ATA 33-24-01 Component Maintenance Manual Control Panel - Pass Signs Rev. 6, 9/14/2012
Korry 410300-001 Boeing S633Z001-150	787-ALL	ATA 30-24-01 Component Maintenance Manual Control Panel - Anti-Ice Rev. 5, 9/14/2012
Korry 410400-001 Boeing S633Z001-170	787-ALL	ATA 30-21-01 Component Maintenance Manual Control Panel - Cabin Pressure Rev. 5, 9/14/2012
Korry 410500-001 Boeing S633Z001-110	787-ALL	ATA 29-11-01 Component Maintenance Manual Control Panel - Hydraulic RAT Rev. 5, 9/14/2012
Korry 410600-001 Boeing S633Z001-140	787-ALL	ATA 28-31-01 Component Maintenance Manual Control Panel - Fuel/Fuel Jettison Rev. 5, 9/14/2012
Korry 410700-001 Boeing S633Z001-160	787-ALL	ATA 21-51-01 Component Maintenance Manual Control Panel - Air Conditioning Rev. 6, 9/14/2012

Korry 411000-001 Boeing S633Z001-130	787-ALL	ATA 80-11-01 Component Maintenance Manual Control Panel - Cargo Fire/Engine Control Rev. 5, 9/14/2012
Korry 411600-002 Boeing S633Z001-190	787-ALL	ATA 27-02-01 Component Maintenance Manual Control Panel - PFC/IRS/HR Rev. 5, 9/14/2012
Korry 411700-002 Boeing S633Z001-181	787-ALL	ATA 30-41-01 Component Maintenance Manual Control Panel - Window Heat/Emergency Rev. 5, 9/15/2012
Korry 411800-001, -002, -006, -008, -009, -010, -014, - 015, -016 Boeing S633Z001-101	787-ALL	ATA 24-22-01 Component Maintenance Manual Control Panel - Cargo Heat / Misc. Rev. 6, 9/14/2012
Korry 412100-001 Boeing S633Z001-330	787-ALL	ATA 52-51-01 Component Maintenance Manual Control Panel - FD Door Rev. 5, 1/16/2013
Korry 412200-001 Boeing S633Z001-340	787-ALL	ATA 33-11-22 Component Maintenance Manual Control Panel - Aisle Stand Panel/Flood Rev. 5, 1/16/2013
Korry 412400-001 Boeing S633Z001-320	787-ALL	ATA 23-51-01 Component Maintenance Manual Control Panel - Obs Audio OVRD Rev. 5, 1/16/2013
Korry 412600-001 Boeing S633Z001-300	787-ALL	ATA 26-21-01 Component Maintenance Manual Control Panel - Engine Fire Rev. 4, 1/16/2013
Korry 413000-001 413000-003 Boeing S633Z001-420 S633Z001-421	787-ALL	ATA 31-61-01 Component Maintenance Manual Control Panel - Src Select, Captains Rev. 5, 1/16/2013

Korry 413100-001 Boeing S633Z001-480	787-ALL	ATA 32-31-01 Component Maintenance Manual Control Panel - Landing Gear Rev. 6, 1/16/2013
Korry 413200-001 413200-003 Boeing S633Z001-460 S633Z001-461	787-ALL	ATA 31-61-02 Component Maintenance Manual Control Panel - Src Select, First Officers Rev. 6, 1/16/2013
Korry 413300-001 Boeing S633Z001-430	787-ALL	ATA 31-51-01 Component Maintenance Manual Control Panel - Master Wrng, Captains Rev. 5, 1/16/2013
Korry 413400-001 Boeing S633Z001-440	787-ALL	ATA 31-51-02 Component Maintenance Manual Control Panel - Master Wrng, First Officers Rev. 5, 1/16/2013
Korry 413700-002 Boeing S633Z001-400	787-ALL	ATA 33-13-01 Component Maintenance Manual Control Panel - Fwd Brt/Heat, Captains Rev. 6, 1/16/2013
Korry 413800-002 Boeing S633Z001-470	787-ALL	ATA 33-13-02 Component Maintenance Manual Control Panel - Fwd Brt/Heat, First Officers Rev. 6, 1/16/2013
Korry 413900-001 Boeing S633Z001-410	787-ALL	ATA 31-61-03 Component Maintenance Manual Control Panel - Clock/Mic, Captains Rev. 6, 1/16/2013
Korry 414000-001 Boeing S633Z001-450	787-ALL	ATA 31-61-04 Component Maintenance Manual Control Panel - Clock/Mic, First Officers Rev. 6, 1/16/2013
Korry 415000-202 Boeing S633Z001-203	787-ALL	ATA 24-22-02 Component Maintenance Manual PIP Circuit Card Assembly Rev. 1, 11/25/2010

Korry
415030-203

Boeing
S633Z001-203

787-ALL

ATA 52-51-02
Component Maintenance Manual
Dimming Control Circuit Card Assembly
Rev. 1, 12/24/2010